



MODELS

System	Indoor	Outdoor
HSNRPX25	HINRPX25M	HONRPX25
HSNRPX35	HINRPX35M	HONRPX35
HSNRPX50	HINRPX50M	HONRPX50
HSNRPX60	HINRPX60M	HONRPX60
HSNRPX70	HINRPX70M	HONRPX70
HSNRPX80	HINRPX80M	HONRPX80
Ref Only	HINRPX20M	Matching Multi System Only

REFRIGERANT
R32



PX Series Split Type Wall Mounted Air Conditioner Installation Manual

Rinnai

This appliance must be installed in accordance with:

- Manufacturer's Installation Instructions
- Current AS/NZS 3000, AS/NZS 5141, AS/NZS 5149
- Local regulations, including local OH&S requirements, and Municipal Building Codes, including the National Construction Code (NCC).

This appliance must be installed, maintained and removed only by an Authorised Person. Rinnai recommends that this appliance be serviced once a year.

For continued safety of this appliance it must be installed and maintained in accordance with the manufacturer's instructions.



TABLE OF CONTENTS

Warnings and Important Information	5
Accessories	11
Indoor Unit	12
Installation Summary	12
Description	13
Installation Overview	13
Select Installation Location	14
Indoor Installation	14
Determine Location for Wall Hole	15
Drill Wall hole for connective piping	15
Mounting Plate Dimensions	16
Drill Wall Hole	17
Install Refrigerant Pipe & Drain Hose	18
Connect Refrigerant Piping	18
Four sides to exit the piping	18
Connect refrigerant piping	18
Connect Drain Hose	19
Electrical Work Preparation	21
Connect signal and power cables	21
Cable Types	21
Choose The Right Cable Size	22
Connecting Indoor to Outdoor Wiring	23
Wrap Piping & Cables	23
Drain hose must be on bottom	23
Do not wrap ends of piping	23
Mount Indoor Unit	24
Outdoor Installation	25
Select Installation Location	25
Install Drain Joint (Heat Pump only)	26
Anchor Outdoor Unit	28
Connect Signal & Power Cables	29
Choose the right cable size	29
Refrigerant Piping Connection	30
Piping Connection Instructions	30
Pipe Length	30
Connection Instructions – Refrigerant Piping	30

Minimum Bend Radius	31
Instructions for Connecting Piping to Indoor Unit	32
Torque Requirements	32
Connecting Piping to Outdoor Unit	33
Air Evacuation	34
Air Purging & Leakage Test	34
Evacuation Vacuum Method / Leak Test	34
Adding Refrigerant for Longer Line Length	35
Additional Refrigerant per Pipe Length	35
Electrical and Gas Leak Checks	36
Electrical Safety Checks	36
Before Test Run	36
During Test Run	36
Gas Leak Checks	36
Test Run	37
Test Run Instructions	37
Double-Check Pipe Connections	37
If Ambient Temperature Is Below 16°C	37
Final Checklist	38
Checklist	38
Specifications	39
Contacts	44

WARNINGS AND IMPORTANT INFORMATION



READ ALL INSTRUCTIONS BEFORE USING THE APPLIANCE.

Always comply with the following precautions to avoid dangerous situations and to ensure optimum performance.

Failure to carefully read and follow all instructions in this manual can result in equipment malfunction, property damage, personal injury and/or death.

DANGER: Indicates an imminently hazardous situation which, if not avoided, will result in personal injury or death.

WARNINGS: Indicates a potentially hazardous situation which, if not avoided, could result in personal injury or death.

CAUTIONS: Indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury or damage to the appliance. It may also be used to alert against unsafe practices.



REGULATORY

This appliance shall be installed in accordance with:

Manufacturer's Installation Instructions.

Current AS/NZS 3000, AS/NZS 5141, AS/NZS 5149.

Local regulations, including local OH&S requirements, and Municipal Building Codes, including the National Construction Code (NCC).

This appliance must be installed, maintained and removed **ONLY** by an Authorised Person.

For continued safety of this appliance it must be installed and maintained in accordance with the manufacturers instructions.

This appliance uses R32 refrigerant.

This appliance is heavy, use 2 people or mechanical lifting device. Improper lifting may result in serious injury.

Take care when opening or unpacking this appliance. Failure to do so may result in serious injury or product failure.

DO NOT modify the electrical wiring of this appliance. If the control power wiring is damaged or deteriorated then it must be replaced by an authorised person. Failure to do so may result in electric shock, fire, serious injury or product failure.

DO NOT install the air conditioner on an unstable or non level surface or where there may be a danger of it falling. It may result in death, serious injury, or product failure.

DO NOT install the outdoor unit where noise may cause nuisance.

DO NOT install the outdoor unit where it will be exposed to sea wind (salt spray) as this will reduce durability.



MANDATORY INSPECTION PRIOR TO INSTALLATION

Immediately report any damage or discrepancies to the Supplier of the appliance. This appliance was inspected and tested at the time of manufacture and packaging, and released for transportation without known damage. Upon receipt, inspect the exterior for evidence of rough handling in shipment. Ensure that the appliance is labelled correctly for the gas and electrical supply, and/or other services it is intended to be connected to.

For safety and warranty purposes, appliances that may be damaged or incorrect **MUST NOT** be installed or operated under any circumstances. Installation of damaged or incorrect appliances may contravene local government regulations. Rinnai disclaims any liability or responsibility whatsoever in relation to the installation or operation of damaged or incorrect appliances.



INSTALLATION

This appliance shall be installed in accordance with local electrical safety regulations by an authorised person such as a licensed electrician. Contact an authorised service technician for repair or maintenance of this appliance.

Only use the included accessories, parts, and specified parts for installation. Using non-standard parts can cause water leakage, electrical shock, fire, and can cause the unit to fail.

Install the unit in a firm location that can support the unit's weight. If the chosen location cannot support the unit's weight, or the installation is not done properly, the unit may drop and cause serious injury and damage.

DO NOT turn on the power until all work has been completed.

When moving or relocating the air conditioner, consult experienced service technicians for disconnection and reinstallation of the unit.

How to install the appliance to its support, please read the information for details in "indoor unit installation" and "outdoor unit installation" sections.

For units that have an auxiliary electric heater, **DO NOT** install the unit within 1 meter (3 feet) of any combustible materials.

DO NOT install the unit in a location that may be exposed to combustible gas leaks. If combustible gas accumulates around the unit, it may cause fire.

Install drainage piping according to the instructions in this manual. Improper drainage may cause water damage to your home and property.

This appliance is a Type 1 Electrical Appliance.

Make sure the live wire, neutral wire and earth wire in the power socket are properly connected. Inadequate or incorrect electrical connections may cause fire or electric shock.

The yellow-green wire in air conditioner is the earthing wire which cannot be used for other purposes. Improper earthing may cause electric shock.

The circuit breaker must have the functions of magnetic tripping and heat tripping to prevent short circuit and overload.

Use a standard circuit breaker and fuse conforming with the rating of the appliances.

The unit must be earthed in accordance with local regulations.

Connect all wiring tightly. Failure to do so may result in electric shock or product failure.

DO NOT supply power to the unit until all wiring and tubing are completed.

Select an installation location where the components can be mounted securely and accessible for service and replacement.

Make sure tubing is properly insulated to ensure optimum performance.

Install the drain hose properly for smooth drainage of condensed water.

Make sure to check for and rectify any refrigerant leaks after you install or repair the unit.

This appliance uses R32 (difluoromethane) refrigerant, which is a flammable gas class 2.2 according to AS/NZS 1677 and must be handled by a refrigeration mechanic with appropriate Australian refrigerant handling licence.



WARNING Risk of fire / flammable material. If the refrigerant is leaked, together with an external ignition source, there is a possibility of ignition.



Read the **OPERATING INSTRUCTIONS** carefully before operation.



Service personnel are required to carefully read the **OPERATING INSTRUCTIONS** and **INSTALLATION MANUAL** before operation.



Further information is available in the **OPERATING INSTRUCTIONS**, **INSTALLATION MANUAL**, and the like.

Certain levels of refrigerant require minimum room sizes. Please ensure that these minimum room sizes are adhered to for standard installations (up to 10m pipe length). If larger refrigerant charges than standard are used then please consult AS/NZS 60335.2.40 to determine the safe minimum floor area for the installation.

Make sure that the area has been made safe by having suitable ventilation and is free from ignition sources before charging or releasing the charge of R32.

Model	HSNRPX25	HSNRPX35	HSNRPX50	HSNRPX60	HSNRPX70	HSNRPX80
Standard Charge (g)	850	900	1200	1200	1400	1400
Minimum Floor Area (m ²)	4.0	4.0	4.0	4.0	4.0	4.0



WARNINGS FOR PRODUCT USE

If an abnormal situation arises (like a burning smell), immediately turn off the unit and disconnect the power. Call your dealer for instructions to avoid electric shock, fire or injury.

DO NOT insert fingers, rods or other objects into the air inlet or outlet. This may cause injury, since the fan may be rotating at high speeds.

DO NOT use flammable sprays such as hair spray, lacquer or paint near the unit. This may cause fire or combustion.

DO NOT operate the air conditioner in places near or around combustible gases. Emitted gas may collect around the unit and cause explosion.

DO NOT operate your air conditioner in a wet room such as a bathroom or laundry room. Too much exposure to water can cause electrical components to short circuit.

DO NOT expose your body directly to cool air for a prolonged period of time.

DO NOT allow children to play with the air conditioner. Children must be supervised around the unit at all times.

If the air conditioner is used together with burners or other heating devices, thoroughly ventilate the room to avoid oxygen deficiency.

In certain functional environments, such as kitchens, server rooms, etc., the use of specially designed air-conditioning units is highly recommended.



OPERATION

DO NOT let the air conditioner run for extended periods when the humidity is very high or when doors or windows are left open. As this may result in an excessive operational loading and lead to product failure.

DO NOT cover or place articles on any part of this appliance.

DO NOT touch, operate or clean the air conditioner with wet hands. It may result in electric shock or product failure.

DO NOT insert hands or other objects through the air inlet or outlet while the appliance is operating. It may result in electric shock or product failure.

DO NOT place a heater or other heating appliances near this appliance, always ensure sufficient ventilation when using this appliance and a heating appliance at the same time. Failure to do so may result in product mis-operation.

Turn main power off before cleaning. Failure to do so may result in fire, electric shock, or product failure.

DO NOT use solvents, abrasives or harsh detergent to clean any part or surface of this appliance or spray water or allow liquids to enter the indoor unit. The enclosure of the appliance and remote control can be cleaned using a soft, damp cloth and a mild detergent.

NEVER touch the metal parts of the air conditioner when you remove the air filter. It may result in electric shock or product failure.

DO NOT leave flammable materials near the appliance. It may result in explosion or fire.

If there is excessive noise, smell or smoke coming from the appliance, turn the appliance off, isolate the power supply and contact a service agent.

DO NOT operate the appliance if it has been submerged into water due to flooding, contact a service agent. Failure to do so may result in electric shock, fire, serious injury, or product failure.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they **DO NOT** play with the appliance.

The air conditioning system is designed to achieve consumer comfort. It is **NOT** designed for commercial applications requiring a controlled atmosphere (i.e. computer rooms, food preservation, etc.)

DO NOT block the inlet or outlet of air flow. It may result product in failure.

DO NOT drink the condensate water drained from the appliance. This condensate is not potable and may present a health risk if consumed.

DO NOT expose people, animals or plants directly to the cold or hot discharge of the appliance. It may result in serious injury.

DO NOT mix the batteries for the remote control with other types of batteries or mix new batteries with used batteries. Failure to do so may result in product failure. **STOP** using the remote control if there is a battery fluid leak.

OPERATION RANGE LIMITATIONS

The table below indicates the temperature ranges the air conditioner can be operated within.

MODE	Cool Mode	Heat Mode	Dry Mode
Room Temperature	16°C ~ 32°C	0°C ~ 30°C	10°C ~ 32°C
Outdoor Temperature	-15°C ~ 50°C	-15°C ~ 24°C	0°C ~ 50°C



CLEANING AND MAINTENANCE WARNINGS

Turn off the device and disconnect the power before cleaning. Failure to do so can cause electrical shock.

DO NOT clean the air conditioner with excessive amounts of water.

DO NOT clean the air conditioner with combustible cleaning agents. Combustible cleaning agents can cause fire or deformation.



OPERATING CAUTIONS

Turn off the air conditioner and disconnect the power if you are not going to use it for a long time.

Turn off and unplug the unit during storms.

Make sure that water condensation can drain unhindered from the unit.

DO NOT operate the air conditioner with wet hands. This may cause electric shock.

DO NOT use device for any other purpose than its intended use.

DO NOT climb onto or place objects on top of the outdoor unit.

DO NOT allow the air conditioner to operate for long periods of time with doors or windows open, or if the humidity is very high.



ELECTRICAL WARNINGS

Only use the specified power cord. If the power cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

Keep power plug clean. Remove any dust or grime that accumulates on or around the plug. Dirty plugs can cause fire or electric shock.

DO NOT pull power cord to unplug unit. Hold the plug firmly and pull it from the outlet. Pulling directly on the cord can damage it, which can lead to fire or electric shock.

DO NOT modify the length of the power supply cord or use an extension cord to power the unit.

DO NOT share the electrical outlet with other appliances. Improper or insufficient power supply can cause fire or electrical shock.

The product must be properly grounded at the time of installation, or electrical shock may occur.

For all electrical work, follow all local and national wiring standards, regulations, and the

Installation Manual. Connect cables tightly, and clamp them securely to prevent external forces from damaging the terminal. Improper electrical connections can overheat and cause fire, and may also cause shock. All electrical connections must be made according to the Electrical Connection

Diagram located on the panels of the indoor and outdoor units.

All wiring must be properly arranged to ensure that the control board cover can close properly. If the control board cover is not closed properly, it can lead to corrosion and cause the connection points on the terminal to heat up, catch fire, or cause electrical shock.

If connecting power to fixed wiring, an all-pole disconnection device which has at least 3mm clearances in all poles, and have a leakage current that may exceed 10mA, the residual current device (RCD) having a rated residual operating current not exceeding 30mA, and disconnection must be incorporated in the fixed wiring in accordance with the wiring rules.



FUSE SPECIFICATIONS

The air conditioner’s circuit board (PCB) is designed with a fuse to provide overcurrent protection.

The specifications of the fuse are printed on the circuit board ,such as:

T3.15AL/250VAC, T5AL/250VAC, T3.15A/250VAC, T5A/250VAC, T20A/250VAC, T30A/250VAC,etc.

NOTE: For the units using R32 refrigerant, only the blast-proof ceramic fuse can be used.



FLUORINATED GASES

This air-conditioning unit contains fluorinated greenhouse gases. For specific information on the type of gas and the amount, please refer to the relevant label on the appliance itself or the “Operation Manual” in the packaging of the outdoor unit.

Installation, service, maintenance and repair of this unit must be performed by a certified technician.

Product uninstallation and recycling must be performed by a certified technician.

For equipment that contains fluorinated greenhouse gases in quantities of 5 tonnes of CO₂ equivalent or more, but of less than 50 tonnes of CO₂ equivalent, if the system has a leak detection system installed, it must be checked for leaks at least every 24 months.

When the unit is checked for leaks, proper record-keeping of all checks is strongly recommended.



This appliance contains an UV emitter. Do not stare at the light source. The appliance must be disconnected from the supply mains before any cleaning or other maintenance.

UV-C LAMP

(Applicable to the unit contains an UV-C lamp only)

This appliance contains a UV-C lamp. Read the maintenance instructions before opening the appliance.












- Do not operate UV-C lamps outside of the appliance.
- Appliances that are obviously damaged must not be operated.
- Unintended use of the appliance or damage to the housing may result in the escape of dangerous UV-C radiation. UV-C radiation may, even in small doses, cause harm to the eyes and skin.
- Before opening doors and access panels bearing the ULTRAVIOLET RADIATION hazard symbol for the conducting USER MAINTENANCE, it is recommended to disconnect the power.
- The UV-C lamp can not be cleaned, repaired and replaced.
- UV-C BARRIERS bearing the ULTRAVIOLET RADIATION hazard symbol should not be removed.


ACCESSORIES

The air conditioning system comes with the following accessories. Use all of the installation parts and accessories to install the air conditioner.

Improper installation may result in water leakage, electrical shock and fire, or cause the equipment to fail.


The items are not included with the air conditioner must be purchased separately.

Name of Accessories	Q'ty(pc)	Shape	Name of Accessories	Q'ty(pc)	Shape
Manual	2~3		Remote controller	1	
Drain joint (for cooling & heating models)	1		Battery	2	
Seal (for cooling & heating models)	1		Remote controller holder(optional)	1	
Mounting plate	1		Fixing screw for remote controller holder(optional)	2	
Anchor	5~8 (depending on models)		Small Filter (Need to be installed on the back of main air filter by the authorised technician while installing the machine)	1~2 (depending on models)	
Mounting plate fixing screw	5~8 (depending on models)				


Name	Shape	Cm	Quantity (PC)
Connecting pipe assembly	Liquid side	Φ 6.35	Parts you must purchase separately. Consult the dealer about the proper pipe size of the unit you purchased.
		Φ 9.52	
	Gas side	Φ 9.52	
		Φ 12.7	
		Φ 16	
		Φ 19	
Magnetic ring and belt (if supplied, please refer to the wiring diagram to install it on the connective cable.)		Pass the belt through the hole of the Magnetic ring to fix it on the cable	Varies by model

INSTALLATION SUMMARY


Indoor Unit




Select Installation Location




Attach Mounting Plate




Determine Wall Hole Position




Drill Wall Hole




Connect Piping




Connect Wiring



Prepare Drain Hose



Wrap Piping and Cable




Mount Indoor Unit




ILLUSTRATIONS

Illustrations in this manual are for explanatory purposes. The actual shape of your indoor unit may be slightly different. The actual shape shall prevail.

Installation Overview



- ① Wall Mounting Plate
- ② Front Panel
- ③ Louvre
- ④ Functional Filter
- ⑤ Drainage Pipe
- ⑥ Signal Cable
- ⑦ Refrigerant Piping
- ⑧ Remote Controller
- ⑨ Remote Controller Holder
- ⑩ Outdoor Unit Power Cable (Purchase Separately)



Equipment required for installation




Gloves



Screwdriver & wrench



Hammer drill



Core drill



Goggles & masks



Vinyl tape

INDOOR INSTALLATION

Select Installation Location




Illustrations in this manual are for explanatory purposes. The actual shape of your indoor unit may be slightly different. The actual shape shall prevail.

Before installing the indoor unit, refer to the label on the product box to make sure that the model number of the indoor unit matches the model number of the outdoor unit.

Correct installation locations meet the following standards:




Good air circulation




Convenient drainage



Noise from the unit will not disturb other people.



- Firm and solid—the location will not vibrate
- Strong enough to support the weight of the unit



- A location at least one metre from all other electrical devices (e.g., TV, radio, computer)

DO NOT install unit in the following locations:

- Near any source of heat, steam, or combustible gas
- Near flammable items such as curtains or clothing
- Near any obstacle that might block air circulation
- Near the doorway
- In a location subject to direct sunlight



PRODUCT INSTALLATION

If there is no fixed refrigerant piping:

While choosing a location, be aware that you should leave ample room for a wall hole (see

Drill wall hole for connective piping step) for the signal cable and refrigerant piping that connect the indoor and outdoor units. The default position for all piping is the right side of the indoor unit (while facing the unit). However, the unit can accommodate piping to both the left and right.

Drill Wall hole for connective piping




Illustrations in this manual are for explanatory purposes. The actual shape of your indoor unit may be slightly different. The actual shape shall prevail.

Determine Location for Wall Hole

If the wall is made of brick, concrete, or similar material, drill 5mm-diameter (0.2in-diameter) holes in the wall and insert the sleeve anchors provided. Then secure the mounting plate to the wall by tightening the screws directly into the clip anchors.


STEP 1

Remove the screw which attaches to the mounting plate at the back of the indoor unit.



STEP 2

Secure the mounting plate to the wall with the screws provided. Make sure that the mounting plate is flat against the wall.




STEP 3

Confirm the mounting plate you own.


Different models have different mounting plates. Refer to following mounting plate dimensions to help you determine the optimal position. The shape of the mounting plate may be lightly different, but the installation dimensions are the same.

Mounting Plate Dimensions


HINRPX20M




**HINRPX25M /
HINRPX35M**



**HINRPX50M /
HINRPX60M**



**HINRPX70M /
HINRPX80M**



Measurements are in mm


Drill Wall Hole




When drilling the wall hole, make sure to avoid wires, plumbing, and other sensitive components.

STEP 1

Using a 65mm or 90mm core drill (depending on models), drill a hole in the wall. Make sure that the hole is drilled at a slight downward angle, so that the outdoor end of the hole is lower than the indoor end by about 5mm to 7mm. This will ensure proper water drainage.




Using a 65mm or 90mm core drill (depending on models)



Drill the wall hole

STEP 2

Place the protective wall cuff in the hole. This protects the edges of the hole and will help seal it when you finish the installation process.



Place the protective wall cuff in the hole.



The size of the wall hole is determined by the connective pipes. When the pipe size of the gas side is 16mm or more, the wall hole should be 90mm. When the pipe size of gas side is less than Φ16mm, the wall hole should be.

Install Refrigerant Pipe & Drain Hose




The refrigerant piping is inside an insulating sleeve attached to the back of the unit. You must prepare the piping before passing it through the hole in the wall. Refer to the Refrigerant Piping connection section of this manual for detailed instructions on pipe flaring and flare torque requirements, technique, etc..

CONNECT REFRIGERANT PIPING


Four sides to exit the piping

Based on the position of the wall hole relative to the mounting plate, choose the side from which the piping will exit the unit. You have four options for the exit direction of the piping.



Connect refrigerant piping

1. If the wall hole is behind the unit, keep the knock-out panel in place. If the wall hole is to the side of the indoor unit, remove the plastic knock-out panel from that side of the unit. Use pliers or scissors if the plastic panel is too difficult to remove by hand.



2. Groove has been made in the knock-out panel in order to cut it conveniently. The size of the slot is determined by the diameter of piping.
3. If existing connective piping is already embedded in the wall, proceed directly to the Connect Drain Hose step. If there is no embedded piping, connect the indoor unit's refrigerant piping to the connective piping that will join the indoor and outdoor units. "Refrigerant Piping Connection" on page 30 section of this manual for detailed instructions.




Be extremely careful not to dent or damage the piping while bending them away from the unit. Any dents in the piping will affect the unit's performance.



For the units using the following pipe connectors, please strictly perform the piping work in accordance with the following instructions.


Before performing the refrigerant piping connection, always wear work gloves and goggles, and remember that the connectors A and B are not allowed to face people directly. Keep pressing the cross-shape part of connector B with a tool for about 5~10 seconds until the red protruding point of connector A retracts completely.

Remove connectors A and B, then perform the refrigerant piping connection between indoor unit and outdoor unit.



- Before performing the refrigerant piping connection, always wear work gloves and goggles, and remember that the connectors A and B are not allowed to face people directly.
- Keep pressing the cross-shape part of connector B with a tool for about 5~10 seconds until the red protruding point of connector A retracts completely.
- Remove connectors A and B, then perform the refrigerant piping connection between indoor unit and outdoor unit.

Connect Drain Hose




The drain hose can be attached to the left or right side. To ensure proper drainage, attach the drain hose on the same side that your refrigerant piping exits the unit. Attach drain hose extension (purchased separately) to the end of drain hose.

- Wrap the connection point firmly with Teflon tape to ensure a good seal and to prevent leaks.
- For the portion of the drain hose that will remain indoors, wrap it with foam pipe insulation to prevent condensation.
- Remove the air filter and pour a small amount of water into the drain pan to make sure that water flows from the unit smoothly.



PLUG THE UNUSED DRAIN HOLE




To prevent unwanted leaks you must plug the unused drain hole with the rubber plug provided.




DRAIN HOSE REPLACEMENT

Make sure to arrange the drain hose according to the following diagrams.




CORRECT

Make sure there are no kinks or dent in drain hose to ensure proper drainage.




NOT CORRECT

Kinks in the drain hose will create water traps.



NOT CORRECT

Kinks in the drain hose will create water traps.



NOT CORRECT

Do not place the end of the drain hose in water or in containers that collect water. This will prevent proper drainage.

Electrical Work Preparation



BEFORE PERFORMING ANY ELECTRICAL WORK, READ THESE REGULATIONS.

BEFORE PERFORMING ANY ELECTRICAL OR WIRING WORK, TURN OFF THE MAIN POWER TO THE SYSTEM.

1. All wiring must comply with local and national electrical codes, regulations and must be installed by a licensed electrician.
2. All electrical connections must be made according to the Electrical Connection Diagram located on the panels of the indoor and outdoor units.
3. If there is a serious safety issue with the power supply, stop work immediately. Explain your reasoning to the client, and refuse to install the unit until the safety issue is properly resolved.
4. If connecting power to fixed wiring, a switch or circuit breaker that disconnects all poles and has a contact separation of at least 3mm must be incorporated in the fixed wiring. The qualified technician must use an approved circuit breaker or switch.
5. Only connect the unit to an individual branch circuit outlet. Do not connect another appliance to that outlet.
6. Make sure to properly ground the air conditioner.
7. Every wire must be firmly connected. Loose wiring can cause the terminal to overheat, resulting in product malfunction and possible fire.
8. Do not let wires touch or rest against refrigerant tubing, the compressor, or any moving parts within the unit.
9. To avoid getting an electric shock, never touch the electrical components soon after the power supply has been turned off. After turning off the power, always wait 10 minutes or more before you touch the electrical components.
10. Power voltage should be within 90-110% of rated voltage. Insufficient power supply can cause malfunction, electrical shock, or fire.



All wiring must be performed strictly in accordance with the wiring diagram located on the back of the Indoor Unit's front panel.

Connect signal and power cables

The signal cable enables communication between the indoor and outdoor units. You must first choose the right cable size before preparing it for connection.

Cable Types

For cable types or equivalent, please refer to AS/NZS 3000 & local rules and regulations.



Please choose the right cable size according to local and national rules

INDOOR INSTALLATION

Choose The Right Cable Size


The size of the power supply cable, signal cable, fuse, and switch needed is determined by the maximum current of the unit. The maximum current is indicated on the nameplate located on the side panel of the unit. Refer to this nameplate to choose the right cable, fuse, or switch.

1. Open front panel of the indoor unit.
2. Using a screwdriver, open the wire box cover on the right side of the unit. This will reveal the terminal block.
3. Unscrew the cable clamp below the terminal block and place it to the side.
4. Facing the back of the unit, remove the plastic panel on the bottom left-hand side.
5. Feed the signal wire through this slot, from the back of the unit to the front.
6. Facing the front of the unit, connect the wire according to the indoor unit's wiring diagram, connect the U-lug and firmly screw each wire to its corresponding terminal.
7. After checking to make sure every connection is secure, use the cable clamp to fasten the signal cable to the unit. Screw the cable clamp down tightly.
8. Replace the wire cover on the front of the unit, and the plastic panel on the back.



DO NOT MIX UP LIVE AND NEUTRAL WIRES


This is dangerous, and can cause the air conditioning unit to malfunction.



For some units that require on-site connection of power cords, it is necessary to remove the front frame first, thread the power cable through the cable-cross hole in the rat baffle at the back of the indoor unit, and then pull it out from the front side, secure it with a cable clip as shown in the diagram (right).


After the power cord passes through the cable clamp, strip the wire 10mm from the end, and then connect the wire to the terminal.

Strip the wire 10mm from the end




CONNECTING INDOOR TO OUTDOOR WIRING

Indoor power supply models



Outdoor power supply models



Wrap Piping & Cables



Before passing the piping, and drain hose through the wall hole, you must bundle them together to save space, protect them, and insulate them.

STEP 1

Bundle the drain hose, refrigerant pipes as shown in Figure on right.

STEP 2



Using adhesive vinyl tape, attach the drain hose to the underside of the refrigerant pipes.

STEP 3

Using insulation tape, wrap the refrigerant pipes, and drain hose tightly together. Double-check that all items are bundled.

STEP 4

After completing the wiring and piping connection, reinstall the lower frame.





Drain hose must be on bottom

Make sure that the drain hose is at the bottom of the bundle. Putting the drain hose at the top of the bundle can cause the drain pan to overflow, which can lead to fire or water damage.


Do not wrap ends of piping

When wrapping the bundle, keep the ends of the piping unwrapped. You need to access them to test for leaks at the end of the installation process (refer to Electrical Checks and Leak Checks section of this manual).



Mount Indoor Unit



Holder at the back of the unit



Use the holder at the back of the unit against the mounting plate to prop up the unit



Move to left or right

If you installed new connective piping to the outdoor unit, do the following:

- If you have already passed the refrigerant piping through the hole in the wall, proceed to Step 4.
- Otherwise, double-check that the ends of the refrigerant pipes are sealed to prevent dirt or foreign materials from entering the pipes.
- Slowly pass the wrapped bundle of refrigerant pipes, drain hose, and signal wire through the hole in the wall.
- Hook the top of the indoor unit on the upper hook of the mounting plate.
- Check that unit is hooked firmly on mounting by applying slight pressure to the left and right-hand sides of the unit. The unit should not jiggle or shift.
- Using even pressure, push down on the bottom half of the unit. Keep pushing down until the unit snaps onto the hooks along the bottom of the mounting plate.
- Again, check that the unit is firmly mounted by applying slight pressure to the left and the right-hand sides of the unit.

If refrigerant piping is already embedded in the wall, do the following:

- Hook the top of the indoor unit on the upper hook of the mounting plate. Use the holder at the back of the unit to prop up the unit, giving you enough room to connect the refrigerant piping, signal cable, and drain hose.
- Connect drain hose and refrigerant piping (refer to **Refrigerant Piping Connection** section of this manual for instructions). Keep pipe connection point exposed to perform the leak test (refer to **Electrical Checks** and **Leak Checks** section of this manual).
- After the leak test, wrap the connection point with insulation tape. Release the holder that is propping up the unit.
- Using even pressure, push down on the bottom half of the unit. Keep pushing down until the unit snaps onto the hooks along the bottom of the mounting plate.



Keep in mind that the hooks on the mounting plate are smaller than the holes on the back of the unit. If you find that you don't have ample room to connect embedded pipes to the indoor unit, the unit can be adjusted left or right by about 50mm, depending on the model.

OUTDOOR INSTALLATION


Select Installation Location



PRIOR TO INSTALLATION

Before installing the outdoor unit, you must choose an appropriate location. The following are standards that will help you choose an appropriate location for the unit.

Figure 1. Outdoor Unit Clearances



Outdoor Installation Location must meet the following requirements

- Select the location where exposure to direct sunlight and strong wind are minimised.
- Select the location where the outdoor unit can be securely mounted.
- Select the location where the noise and air flow will not cause nuisance.
- Ensure there are no obstructions in the air flow path.
- Ensure good air circulation and ventilation.
- Ensure the outdoor unit is located so it can be accessed for service and replacement.
- Select a firm and solid foundation, a location which can support the unit and will not vibrate.
- Where snowfall is anticipated, take appropriate measures to prevent ice build-up and coil damage.
- Meets all clearance requirements as shown in Figure above.



Install the unit by following local codes and regulations, there may be slight differences between different regions.



SPECIAL CONSIDERATIONS FOR EXTREME WEATHER

If the unit is exposed to heavy wind:

Install unit so that air outlet fan is at a 90° angle to the direction of the wind. If needed, build a barrier in front of the unit to protect it from extremely heavy winds. See Figures below.

If the unit is frequently exposed to heavy rain or snow:


Build a shelter above the unit to protect it from the rain or snow. Be careful not to obstruct air flow around the unit.

If the unit is frequently exposed to salty air (seaside):

Use outdoor unit that is specially designed to resist corrosion.

OUTDOOR INSTALLATION

Figure 1. Considerations for Extreme Weather



DO NOT install unit in the following locations:

- Near an obstacle that will block air inlets and outlets.
- Near a public street, crowded areas, or where noise from the unit will disturb others.
- Near animals or plants that will be harmed by hot air discharge.
- Near any source of combustible gas.
- In a location that is exposed to large amounts of dust
- In a location exposed to a excessive amounts of salty air.


Install Drain Joint (Heat Pump only)



Before bolting the outdoor unit in place, you must install the drain joint at the bottom of the unit. For the units with base pan built-in with multiple holes for proper draining during defrost, the drain joint is no need to be installed.


STEP 1

Find out the base pan hole of outdoor unit.



STEP 2

- Fit the rubber seal on the end of the drain joint that will connect to the outdoor unit.
- Insert the drain joint into the hole in the base pan of the unit. The drain joint will click in place.
- Connect a drain hose extension (not included) to the drain joint to redirect water from the unit during heating mode.




In cold climates, make sure that the drain hose is as vertical as possible to ensure swift water drainage. If water drains too slowly, it can freeze in the hose and flood the unit.

Anchor Outdoor Unit




When drilling into concrete, eye protection is recommended at all times.

- The outdoor unit can be anchored to the ground or to a wall-mounted bracket with bolt (M10). Prepare the installation base of the unit according to the dimensions below.
- The following is a list of different outdoor unit sizes and the distance between their mounting feet. Prepare the installation base of the unit according to the dimensions below.



Top view



Front view

Outdoor Unit Dimensions (mm) W x H x D	Mounting Hole Pitch Dimensions	
	Distance A (mm)	Distance B (mm)
765 x 555 x 303	452	286
805 x 554 x 330	511	317
890 x 673 x 342	673	354

If you wish to install the unit on the ground or on a concrete mounting platform, do the following:

- Mark the positions for four expansion bolts based on dimensions chart.
- Pre-drill holes for expansion bolts.
- Place a nut on the end of each expansion bolt.
- Hammer expansion bolts into the pre-drilled holes.
- Remove the nuts from expansion bolts, and place outdoor unit on bolts.
- Put washer on each expansion bolt, then replace the nuts.
- Using a wrench, tighten each nut until snug.

If you wish to install the unit on a wall-mounted bracket, do the following:

- Mark the position of bracket holes based on dimensions chart.
- Pre-drill the holes for the expansion bolts.
- Place a washer and nut on the end of each expansion bolt.
- Thread expansion bolts through holes in mounting brackets, put mounting brackets in position, and hammer expansion bolts into the wall.
- Check that the mounting brackets are level.
- Carefully lift unit and place its mounting feet on brackets.
- Bolt the unit firmly to the brackets.
- If allowed, install the unit with rubber gaskets to reduce vibrations and noise.



Make sure that the wall is made of solid brick, concrete, or of similarly strong material. The wall must be able to support at least four times the weight of the unit.

Connect Signal & Power Cables



ALL WIRING WORK MUST BE PERFORMED STRICTLY IN ACCORDANCE WITH THE WIRING DIAGRAM LOCATED INSIDE OF WIRE COVER OF THE OUTDOOR UNIT.

BEFORE PERFORMING ANY ELECTRICAL OR WIRING WORK, TURN OFF THE MAIN POWER TO THE SYSTEM.

Choose the right cable size

The size of the power supply cable, signal cable, fuse, and switch needed is determined by the maximum current of the unit. The maximum current is indicated on the nameplate located on the side panel of the unit.

Please choose the right cable according to the "Cable Types" on page 21

- Using wire strippers, strip the rubber jacket from both ends of cable to reveal about 40mm of the wires inside.
- Strip the insulation from the ends of the wires.
- Using a wire crimper, crimp U-lugs on the ends of the wires.

Pay attention to live wire

While crimping wires, make sure you clearly distinguish the Live ("L") Wire from other wires.


The outside unit's terminal block is protected by an electrical wiring cover on the side of the unit.

A comprehensive wiring diagram is attached to the inside of the wiring cover.


- Unscrew the electrical wiring cover and remove it.
- Unscrew the cable clamp below the terminal block and place it to the side.
- Connect the wire according to the wiring diagram, and firmly screw the U-lug of each wire to its corresponding terminal.
- After checking to make sure every connection is secure, loop the wires around to prevent rain water from flowing into the terminal.
- Using the cable clamp, fasten the cable to the unit. Screw the cable clamp down tightly.
- Insulate unused wires with PVC electrical tape.
- Arrange them so that they do not touch any electrical or metal parts.
- Replace the wire cover on the side of the unit, and screw it in place.




The unit you purchased may be slightly different. The illustrations are for explanatory purposes. The actual shape shall prevail.



If the cable clamp looks like the following, please select the appropriate through-hole according to the diameter of the wire.



Three hole sizes: Small, Large, Medium



When the cable is not fastened enough, use the buckle to prop it up so it can be clamped tightly.

REFRIGERANT PIPING CONNECTION

Piping Connection Instructions



WHEN CONNECTING REFRIGERANT PIPING, **DO NOT** LET SUBSTANCES OR GASES OTHER THAN THE SPECIFIED REFRIGERANT ENTER THE UNIT. THE PRESENCE OF OTHER GASES OR SUBSTANCES WILL LOWER THE UNIT'S CAPACITY, AND CAN CAUSE ABNORMALLY HIGH PRESSURE IN THE REFRIGERATION CYCLE. THIS CAN CAUSE EXPLOSION AND INJURY.

PIPE LENGTH

The length of refrigerant piping will affect the performance and energy efficiency of the unit. Nominal efficiency is tested on units with a pipe length of 5 metres. A minimum pipe run of 3 metres is required to minimise vibration & excessive noise.

Refer to the table below for specifications on the maximum length and drop height of piping.

Maximum Length and Drop Height of Refrigerant Piping per Unit Model


Model	Capacity (kW)	Length (m)	Max Drop Height (m)
R32 Inverter Split Air Conditioner	<4.4	25	10
	≥4.4 and <7	30	20
	≥7 and <10.5	50	25

Connection Instructions – Refrigerant Piping

STEP 1: CUT PIPES

When preparing refrigerant pipes, take extra care to cut and flare them properly. This will ensure efficient operation and minimise the need for future maintenance.

- Measure the distance between the indoor and outdoor units.
- Using a pipe cutter, cut the pipe a little longer than the measured distance.
- Make sure that the pipe is cut at a perfect 90° angle.



DO NOT damage, dent, or deform the pipe while cutting. This will drastically reduce the heating efficiency of the unit.




You **MUST** check the end of the pipe for cracks and even flaring. Ensure the pipe is sealed.

STEP 2: REMOVE BURRS

Burrs can affect the air-tight seal of refrigerant piping connection. They must be completely removed.


- Hold the pipe at a downward angle to prevent burrs from falling into the pipe.
- Using a reamer or deburring tool, remove all burrs from the cut section of the pipe



STEP 3: FLARE PIPE ENDS

Proper flaring is essential to achieve an airtight seal.


- After removing burrs from cut pipe, seal the ends with PVC tape to prevent foreign materials from entering the pipe.
- Sheath the pipe with insulating material.
- Place flare nuts on both ends of pipe. Make sure they are facing in the right direction, because you can't put them on or change their direction after flaring.



- Remove PVC tape from ends of pipe when ready to perform flaring work.
- Clamp flare form on the end of the pipe.
- The end of the pipe must extend beyond the edge of the flare form in accordance with the dimensions shown in the following table.

Piping extension beyond Flare Form		
Outer Diameter of Pipe (mm)	A (mm)	
	Min.	Max.
Ø 6.35	0.7	1.3
Ø 9.52	1.0	1.6
Ø 12.7	1.0	1.8
Ø 16	2.0	2.2
Ø 19	2.0	2.4

- Place flaring tool onto the form.
- Turn the handle of the flaring tool clockwise until the pipe is fully flared.
- Remove the flaring tool and flare form, then inspect the end of the pipe for cracks and even flaring.




STEP 4: CONNECT PIPES



When connecting refrigerant pipes, be careful not to use excessive torque or to deform the piping in any way. You should first connect the low-pressure pipe, then the high-pressure pipe.

MINIMUM BEND RADIUS


When bending connective refrigerant piping, the minimum bending radius is 10cm.



Instructions for Connecting Piping to Indoor Unit


STEP 1

- Align the centre of the two pipes that you will connect.



STEP 2

- Tighten the flare nut as tightly as possible by hand.
 - Using a spanner, grip the nut on the unit tubing.
 - While firmly gripping the nut on the unit tubing, use a torque wrench to tighten the flare nut according to the torque values in the Torque Requirements table below.
- Loosen the flaring nut slightly, then tighten again.



TORQUE REQUIREMENTS

Outer Diameter of Pipe (mm)	Tightening Torque (N•m)	Flare dimension (B) (mm)	Flare shape
Ø 6.35	18~20	8.4~8.7	
Ø 9.52	32~39	13.2~13.5	
Ø 12.7	49~59	16.2~16.5	
Ø 16	57~71	19.2~19.7	
Ø 19	67~101	23.2~23.7	






DO NOT DEFORM PIPE WHILE CUTTING

Be extra careful not to damage, dent, or deform the pipe while cutting. This will drastically reduce the heating efficiency of the unit.

Connecting Piping to Outdoor Unit



This section still needs to be operated according to the **TORQUE REQUIREMENTS** chart on the previous page.



1. Unscrew the cover from the packed valve on the side of the outdoor unit.
2. Remove protective caps from ends of valves.
3. Align flared pipe end with each valve, and tighten the flare nut as tightly as possible by hand.
4. Using a spanner, grip the body of the valve. Do not grip the nut that seals the service valve.
5. While firmly gripping the body of the valve, use a torque wrench to tighten the flare nut according to the correct torque values.
6. Loosen the flaring nut slightly, then tighten again.
7. Repeat Steps 3 to 6 for the remaining pipe.



USE SPANNER TO GRIP MAIN BODY OF VALVE

Torque from tightening the flare nut can snap off other parts of valve.

AIR EVACUATION

AIR PURGING & LEAKAGE TEST



DO NOT mix any substance other than the specified refrigerant (R32) into refrigerant system.

When refrigerant gas leaks occur, ventilate the room immediately.

R32, as well as other refrigerants, should always be recovered and never be released directly into the environment.

Use a vacuum pump for R32 exclusively. Using the same vacuum pump for different refrigerants may damage the vacuum pump or the unit.



It is necessary to purge air and check for gas leakage after piping work is completed.

If using additional refrigerant, perform air purging from the refrigerant pipes and indoor unit using a vacuum pump, then charge additional refrigerant.


Use a hex socket (3/16") to operate the service valves.

All refrigerant pipe joints to be tightened with a torque wrench at the specified torque.

Evacuation Vacuum Method / Leak Test

STEP 1

- Connect the charge hose of the manifold gauge to service port on the outdoor unit's low pressure valve.
- Connect another charge hose from the manifold gauge to the vacuum pump.
- Open the Low Pressure side of the manifold gauge. Keep the High Pressure side closed.
- Turn on the vacuum pump to evacuate the system.
- Run the vacuum for at least 15 minutes, or until the Compound Meter reads -76cmHg (-10⁵ Pa).
- Close the Low Pressure side of the manifold gauge, and turn off the vacuum pump.
- Wait for 5 minutes, then check that there has been no change in system pressure.






Both the vapour and liquid valve caps **MUST BE** on tight.

STEP 2

- If there is a change in system pressure, refer to Gas Leak Check section for information on how to check for leaks.
- If there is no change in system pressure, unscrew the cap from the packed valve (high pressure valve).
- Insert hexagonal wrench into the packed valve (high pressure valve) and open the valve by turning the wrench in a 1/4 counter-clockwise turn. Listen for gas to exit the system, then close the valve after 5 seconds.
- Watch the Pressure Gauge for one minute to make sure that there is no change in pressure. The Pressure Gauge should read slightly higher than atmospheric pressure.
- Remove the charge hose from the service port.
- Using hexagonal wrench, fully open both the high pressure and low pressure valves.
- Tighten valve caps on all three valves (service port, high pressure, low pressure) by hand. You may tighten it further using a torque wrench if needed.
- The system is now ready to run.



Ensure to open all the valves after evacuation. When opening valve stems, turn the hexagonal wrench until it hits against the stopper. Do not try to force the valve to open further.

Adding Refrigerant for Longer Line Length

Additional refrigerant for longer piping runs can be added either at the time of evacuation of the new installation or while the unit is operating.

Some systems require additional charging depending on pipe lengths. The standard pipe length varies according to local regulations. For example, the standard pipe length may be 7.5m. In other areas, the standard pipe length is 5m. The refrigerant should be charged from the service port on the outdoor unit's low pressure valve.

The additional refrigerant to be charged can be calculated using the formula in the following table.

ADDITIONAL REFRIGERANT PER PIPE LENGTH

Connective Pipe Length (m)	Air Purging Method	Additional Refrigerant	
≤ Standard pipe length	Vacuum Pump	N/A	
> Standard pipe length	Vacuum Pump	Liquid Side: Ø 6.35 R32: (Pipe length – standard length) x 12g/m	Liquid Side: Ø 9.52 R32: (Pipe length – standard length) x 24g/m



It is very easy to overcharge, take caution in charging refrigerant liquid and keep your eye on the scales to avoid overcharging the unit.

Take care not to discharge refrigerant into the atmosphere during installation, re-installation, repair or service.



DO NOT MIX REFRIGERANT TYPES

ELECTRICAL AND GAS LEAK CHECKS



RISK OF ELECTRIC SHOCK

ALL WIRING MUST COMPLY WITH LOCAL AND NATIONAL ELECTRICAL CODES, AND MUST BE INSTALLED BY A LICENSED ELECTRICIAN.



BEFORE TEST RUN

Only perform test run after you have completed the following steps:

- Electrical Safety Checks – Confirm that the unit's electrical system is safe and operating properly
- Gas Leak Checks – Check all flare nut connections and confirm that the system is not leaking
- Confirm that gas and liquid (high and low pressure) valves are fully open

ELECTRICAL SAFETY CHECKS

After installation, confirm that all electrical wiring is installed in accordance with local and national regulations, and according to the Installation Manual.

BEFORE TEST RUN

Check Grounding Work

Measure grounding resistance by visual detection and with grounding resistance tester.

DURING TEST RUN

Check for Electrical Leakage

During the Test Run, use an electro-probe and multimeter to perform a comprehensive electrical leakage test.

If electrical leakage is detected, turn off the unit immediately and call a licensed electrician to find and resolve the cause of the leakage.

GAS LEAK CHECKS


There are two different methods to check for gas leaks.

Soap and Water Method

Using a soft brush, apply soapy water or liquid detergent to all pipe connection points on the indoor unit and outdoor unit. The presence of bubbles indicates a leak.

Leak Detector Method

If using leak detector, refer to the device's operation manual for proper usage instructions.



After Performing Gas Leak Checks

After confirming that the all pipe connection points **DO NOT** leak, replace the valve cover on the outside unit.

TEST RUN INSTRUCTIONS

You should perform the **Test Run** for at least 30 minutes.

- Connect power to the unit.
- Press the **ON/OFF** button on the remote controller to turn it on.
- Press the **MODE** button to scroll through the following functions, one at a time:
 - COOL – Select lowest possible temperature
 - HEAT – Select highest possible temperature
- Let each function run for 5 minutes, and perform the following checks:

List of Checks to Perform	PASS/FAIL	
No electrical leakage		
Unit is properly grounded		
All electrical terminals properly covered		
Indoor and outdoor units are solidly installed		
All pipe connection points do not leak	Outdoor (2):	Indoor (2):
Water drains properly from drain hose		
All piping is properly insulated		
Unit performs COOL function properly		
Unit performs HEAT function properly		
Indoor unit louvers rotate properly		
Indoor unit responds to remote controller		

Double-Check Pipe Connections

During operation, the pressure of the refrigerant circuit will increase. This may reveal leaks that were not present during your initial leak check. Take time during the Test Run to double-check that all refrigerant pipe connection points do not have leaks. Refer to "Gas Leak Checks" on page 36 for instructions.


After the Test Run is successfully completed, and you confirm that all checks points in List of Checks to Perform have PASSED, do the following:

- Using remote control, return unit to normal operating temperature.
- Using insulation tape, wrap the indoor refrigerant pipe connections that you left uncovered during the indoor unit installation process.

If Ambient Temperature Is Below 16°C

You can't use the remote controller to turn on the COOL function when the ambient temperature is below 16°C. In this instance, you can use the MANUAL CONTROL button to test the COOL function.

- Lift the front panel and raise it until it clicks in place.
- The MANUAL CONTROL button is located on the right-hand side of the electrical control box. Press two times to select cool mode.
- Perform Test Run as normal.



CHECKLIST

FINAL CHECKLIST



The checklist is **ONLY** to be completed by an **Authorised Person**.

Check Item	✓	What can happen if not checked
Is the indoor unit installed securely?	<input type="checkbox"/>	Falling, vibration, noise
Has an inspection been made to check for gas leakage?	<input type="checkbox"/>	No cooling or heating
Has all thermal insulation been completed (vapour pipes, liquid pipes, indoor portions of the drain hose extension)?	<input type="checkbox"/>	Condensation
Is the drainage secure?	<input type="checkbox"/>	Water leakage
Are the electric wires installed correctly?	<input type="checkbox"/>	No cooling or heating, may cause electrical shock or electrical fire.
Is the wiring in accordance within the specifications?	<input type="checkbox"/>	Operation failure, electrical fire
Are all inlets / outlets of the indoor and outdoor units free of any obstructions?	<input type="checkbox"/>	No cooling or heating
Are the stop valves open?	<input type="checkbox"/>	No cooling or heating
Are the pipes designed for use with R32?	<input type="checkbox"/>	Pipe or pipe connection leakage
Has a leak test been carried out for the pipe connections?	<input type="checkbox"/>	Pipe connection leakage
Has air purging been carried out?	<input type="checkbox"/>	No cooling or heating
Has the appliance been tested for correct operation?	<input type="checkbox"/>	No cooling or heating
Is the end user fully aware of the operating procedure?	<input type="checkbox"/>	Incorrect operation

If you have answered no to any of the above, you must check and correct before appliance hand-over to customer.

SPECIFICATIONS

RINNAI - PX Series Hi-Wall Split System		HSNRPX25	HSNRPX35	
Nominal Capacity	kW	2.6	3.5	
Power Supply to Outdoor Unit	V - Ph - Hz	220~240 - 1 - 50		
Maximum Input Power (Cooling / Heating)	W	2300		
Maximum Input Current (Cooling / Heating)	A	10	10.5	
Connectivity	-	Wi-Fi Enabled		
Demand Response Enabling Device	-	DRED Enabled		
Cooling	Rated Capacity	kW	2.6	3.5
	Capacity Range		1.03-3.46	0.89-4.04
	Rated Power Input	W	491	802
	Rated Current	A	2.15	3.50
	AEER	W/W	5.3	4.4
	Star Rating (Hot / Average / Cold)	STAR	7 / 6 / 6.5	6 / 5.5 / 6
Heating	Rated Capacity	kW	3.25	3.8
	Capacity Range		1.10-4.19	1.30-5.04
	Rated Power Input	W	703	842
	Rated Current	A	3.0	4.0
	ACOP	W/W	4.61	4.50
	Star Rating (Hot / Average / Cold)	STAR	4 / 3.5 / 3.0	4 / 3.5 / 3
Suitable Area Coverage (up to 2.6m insulated ceiling)	m ²	12-17	16-23	
Indoor Unit Model No.		HINRPX25M	HINRPX35M	
Air Flow (Turbo / Hi / Med / Lo / Min)	L/s	208 / 153 / 111 / 86 / 43	222 / 167 / 125 / 103 / 61	
Moisture Removal	L/h	1.3	1.3	
Air Flow (Turbo / Hi / Med / Lo / Min)	m ³ /h	750 / 550 / 400 / 310 / 155	800 / 600 / 450 / 370 / 220	
Sound Power Level	dB(A)	56.6	60	
Sound Pressure Level @ 1m (Turbo / Hi / Med / Lo / Min)	dB(A)	47 / 39 / 33 / 26.5 / 20.5	46.5 / 39.5 / 33.5 / 27 / 21	
Air Swing Louvres Type	Direction	4-Way Swing		
Dimensions	Dimension (W x D x H)	mm	813 x 201 x 289	813 x 201 x 289
	Packing (W x D x H)		885 x 280 x 358	885 x 280 x 358
	Net / Gross Weight	kg	8.0 / 10.7	8.2 / 10.8
Operating Range	Cooling	°C	16~32	
	Heating		0~30	
Outdoor Unit Model No.		HONRPX25	HONRPX35	
Sound Power Level	dB(A)	60	64	
Sound Pressure Level @ 1m		55.5	55.5	
Dimensions	Dimension (W x D x H)	mm	765 x 303 x 555	805 x 330 x 554
	Packing (W x D x H)		887 x 337 x 610	915 x 370 x 615
	Net / Gross Weight	kg	29.4 / 31.8	31.8 / 34.5
Refrigerant	Type		R32	
	Charged Volume	kg	0.9	0.9
	Pipe Size: Liquid / Gas	mm	6.35 / 9.52	6.35 / 9.52
	Maximum Pipe Length	m	25	25
	Chargeless Length		10	10
	Extra Charge for Lengths >10m	g/m	12	12
	Maximum Vertical Separation	m	10	10
Ambient Temperature Limits	Cooling	°C	-15 ~ 50	-15 ~ 50
	Heating		-15 ~ 24	-15 ~ 24

Capacities tested in accordance with AS/NZS 3823.2, with 5m interconnecting pipe length. With our policy of continuous improvement, we reserve the right to change, or discontinue at any time, specifications or designs without notice.

SPECIFICATIONS

RINNAI - PX Series Hi-Wall Split System			HSNRPX50	HSNRPX60
Nominal Capacity		kW	5.0	6.0
Power Supply to Outdoor Unit		V - Ph - Hz	220~240 - 1 - 50	
Maximum Input Power (Cooling / Heating)		W	3400	
Maximum Input Current (Cooling / Heating)		A	15.5	
Connectivity		-	Wi-Fi Enabled	
Demand Response Enabling Device		-	DRED Enabled	
Cooling	Rated Capacity	kW	5.0	6.0
	Capacity Range		1.45-6.20	1.45-6.2
	Rated Power Input	W	1149	1568
	Rated Current	A	5.10	6.96
	AEER	W/W	4.34	3.821
	Star Rating (Hot / Average / Cold)	STAR	5.5 / 5 / 5.5	4.5 / 4.5 / 5
Heating	Rated Capacity	kW	6.0	6.55
	Capacity Range		1.91-6.75	1.91-6.75
	Rated Power Input	W	1456	1665
	Rated Current	A	6.33	7
	ACOP	W/W	4.115	3.928
	Star Rating (Hot / Average / Cold)	STAR	4 / 3 / 2.5	4. / 3 / 2
Suitable Area Coverage (up to 2.6m insulated ceiling)		m ²	23~33	27~40
Indoor Unit Model No.			HINRPX50M	HINRPX60M
Air Flow (Turbo / Hi / Med / Lo / Min)		L/s	339 / 256 / 183 / 150/89	339 / 256 / 183 / 150 / 89
Moisture Removal		L/h	2.46	2.46
Air Flow (Turbo / Hi / Med / Lo / Min)		m ³ /h	1220 / 920 / 660 / 540 / 320	1220 / 920 / 660 / 540 / 320
Sound Power Level		dB(A)	62.6	62.8
Sound Pressure Level @ 1m (Turbo / Hi / Med / Lo / Min)			49.5 / 43.0 / 36.5 / 28.5 / 19.5	49.5 / 43.0 / 36.5 / 28.5 / 19.5
Air Swing Louvres Type		Direction	4-Way Swing	
Dimensions	Dimension (W x D x H)	mm	975 x 218 x 308	975 x 218 x 308
	Packing (W x D x H)		1065 x 300 x 380	1065 x 300 x 380
	Net / Gross Weight	kg	10.7 / 14.8	10.7 / 14.8
Operating Range	Cooling	°C	16~32	
	Heating		0~30	
Outdoor Unit Model No.			HONRPX50	HONRPX60
Sound Power Level		dB(A)	66.6	66.7
Sound Pressure Level @ 1m			57.5	57.5
Dimensions	Dimension (W x D x H)	mm	890 x 342 x 673	890 x 342 x 673
	Packing (W x D x H)		1030 x 438 x 750	1030 x 438 x 750
	Net / Gross Weight	kg	42.3 / 45.8	42.3 / 45.8
Refrigerant	Type		R32	
	Charged Volume	kg	1.2	1.2
	Pipe Size: Liquid / Gas	mm	6.35 / 12.7	6.35 / 12.7
	Maximum Pipe Length	m	30	30
	Chargeless Length		10	10
	Extra Charge for Lengths >10m	g/m	12	12
	Maximum Vertical Separation	m	20	20
Ambient Temperature Limits	Cooling	°C	-15~50	-15~50
	Heating		-15~24	-15~24

Capacities tested in accordance with AS/NZS 3823.2, with 5m interconnecting pipe length. With our policy of continuous improvement, we reserve the right to change, or discontinue at any time, specifications or designs without notice.

RINNAI - PX Series Hi-Wall Split System			HSNRPX70	HSNRPX80
Nominal Capacity		kW	7.0	8.0
Power Supply to Outdoor Unit		V - Ph - Hz	220~240 - 1 - 50	
Maximum Input Power (Cooling / Heating)		W	4050	
Maximum Input Current (Cooling / Heating)		A	17.5	
Connectivity		-	Wi-Fi Enabled	
Demand Response Enabling Device		-	DRED Enabled	
Cooling	Rated Capacity	kW	7.0	7.95
	Capacity Range		2.7-8.23	2.7-8.23
	Rated Power Input	W	1971	2325
	Rated Current	A	9	10.5
	AEER	W/W	3.55	3.42
	Star Rating (Hot / Average / Cold)	STAR	4 / 3.5 / 4	3.5 / 3.5 / 4
Heating	Rated Capacity	kW	7.7	8.7
	Capacity Range		2.7-8.94	2.7-8.94
	Rated Power Input	W	1983	2395
	Rated Current	A	8.9	10.7
	ACOP	W/W	3.88	3.63
	Star Rating (Hot / Average / Cold)	-	3 / 2.5 / 2	3 / 2.5 / 2
Suitable Area Coverage (up to 2.6m insulated ceiling)		m ²	32~47	36~53
Indoor Unit Model No.			HINRPX70M	HINRPX80M
Air Flow (Turbo / Hi / Med / Lo / Min)		L/s	336 / 289 / 244 / 198 / 114	336 / 289 / 244 / 198 / 114
Moisture Removal		L/h	3.4	3.4
Air Flow (Turbo / Hi / Med / Lo / Min)		m ³ /h	1208 / 1039 / 880 / 714 / 410	1208 / 1039 / 880 / 714 / 410
Sound Power Level		dB(A)	63.9	67.3
Sound Pressure Level @ 1m (Turbo / Hi / Med / Lo / Min)			52 / 46 / 43 / 38 / 37.5	52 / 46 / 43 / 38 / 37.5
Air Swing Louvres Type		Direction	4-Way Swing	
Dimensions	Dimension (W x D x H)	mm	1055 x 231 x 330	1055 x 231 x 330
	Packing (W x D x H)		1140 x 420 x 325	1140 x 420 x 325
	Net / Gross Weight	kg	13.0 / 16.1	13.0 / 16.1
Operating Range	Cooling	°C	16~32	
	Heating		0~30	
Outdoor Unit Model No.			HONRPX70	HONRPX80
Sound Power Level		dB(A)	66.4	69.1
Sound Pressure Level @ 1m			61	61
Dimensions	Dimension (W x D x H)	mm	890 x 342 x 673	890 x 342 x 673
	Packing (W x D x H)		1030 x 438 x 750	1030 x 438 x 750
	Net / Gross Weight	kg	43.8 / 47.4	43.8 / 47.4
Refrigerant	Type		R32	
	Charged Volume	kg	1.4	1.4
	Pipe Size: Liquid / Gas	mm	6.35 / 15.9	6.35 / 15.9
	Maximum Pipe Length	m	50	50
	Chargeless Length		10	10
	Extra Charge for Lengths >10m	g/m	12	12
	Maximum Vertical Separation	m	25	25
Ambient Temperature Limits	Cooling	°C	-15 ~ 50	-15 ~ 50
	Heating		-15 ~ 24	-15 ~ 24

Capacities tested in accordance with AS/NZS 3823.2, with 5m interconnecting pipe length. With our policy of continuous improvement, we reserve the right to change, or discontinue at any time, specifications or designs without notice.

NOTES



Rinnai Australia Pty Ltd

ABN 74 005 138 769 | AU45204

82-88 Mills Road, Braeside, Victoria, 3195
P.O. Box 460, Braeside, Victoria, 3195
Tel: (03) 9271 6625

Customer Support

Tel: 1300 555 545*

Monday to Friday, 8.00 am to 5.00 pm EST.

**Cost of a local call may be higher from a mobile phone.
(National calls from public phones in Australia are free.)*

For further information visit **www.rinnai.com.au**
or email **enquiry@rinnai.com.au**

Rinnai has a Service and Spare Parts network with personnel who are fully trained and equipped to give the best service on your Rinnai appliance. If your appliance requires service, please call Customer Support. Rinnai recommends that this appliance be serviced once a year.

With our policy of continuous improvement, we reserve the right to change, or discontinue at any time, specifications or designs without notice.