



Rinnai Fire Control

App Setup Guide: Pairing Your Fireplace (Android)

1

Step 1 of 15

Open the app

Launch Rinnai Fire Control. You'll see the splash screen with the Rinnai logo and Fire Control branding.




2

Step 2 of 15

Choose how to sign in

On the Welcome Back screen, tap Continue with Google, Microsoft, or Apple to sign in to your account.




3

Step 3 of 15

Pick your Google account

Android shows the Google accounts already set up on your device - tap the one you want to use, or choose Add another account.




4

Step 4 of 15

Start adding your fireplace

On the Find step, make sure your fire is switched ON at the wall and in standby mode, stand near it, then tap Search.




5

Step 5 of 15

Allow location access

Android asks for location access to help find the fireplace's Wi-Fi network. Choose Precise, then While using the app.




6

Step 6 of 15

Allow nearby devices access

You'll also be asked to let Rinnai Fire find, connect to and determine the position of nearby devices - tap Allow to continue.




7

Step 7 of 15

Searching for your fire

The app searches for your fireplace over Bluetooth. Once it's found, you'll see "Found one fire nearby".




8

Step 8 of 15

Connect to the fireplace's Wi-Fi

Android will ask to join a temporary Wi-Fi network created by the fireplace itself (RinnaiWiFi_xxxxxx) - tap Connect.




9

Step 9 of 15

Connecting to your fire


Your device connects to the fireplace directly over its own Wi-Fi network. This only takes a few seconds.



10 Step 10 of 15

Connect to your home Wi-Fi


Select your home network (2.4GHz only, 3+ bars signal), enter the password, then tap Connect Fireplace.



11 Step 11 of 15

Linking your fireplace

The app links the fireplace to your home network. This can take up to 40 seconds - keep the app open until it finishes.




12

Step 12 of 15

You're connected


Your fireplace is now on your home Wi-Fi and ready to control from anywhere in your home. Tap Continue to finish setup.



13 Step 13 of 15

Name your fireplace

Give it a name so it's easy to identify - pick a quick suggestion like Living Room, or type your own, then tap Continue.



14

Step 14 of 15

Enter and confirm the serial number

Find the 10-character serial number on the back of your operation guide or the rating plate inside the firebox. Once it matches a model, tap Confirm & Save.

10:49 •

< Add Fireplace
Step 4 of 4

FIND CONNECT NAME SERIAL

FIREPLACE
Living Room

SERIAL NUMBER *

LJZBBB0010 10/10 characters

Found on the **back of your operation guide** or on the rating plate inside the firebox. 10 characters - no spaces or dashes.

EXAMPLE

RHFE1500D NZ

SERIAL NUMBER: LJZBBB0010

1500 (RHFE1500D)
1500 - New Zealand ✓ Found


Confirm & Save

15

Step 15 of 15

You're ready to go

Setup is complete - your fireplace now appears under the Fire tab, starting in Standby. Tap the power button to turn it on.



Rinnai