

Inverter Cassette

ERROR CODES

Code	Probable Cause	The number of flashes per second	Timer Indicator
E0	Indoor EEPROM (Electrically Erasable Programmable Read-Only Memory) error	1	OFF
E1	Indoor and outdoor unit communication malfunction	2	OFF
E3	Indoor fan speed malfunction	4	OFF
E4	Indoor room temperature sensor error	5	OFF
E5	Evaporator coil temperature sensor error	6	OFF
EC	Refrigerant leak detection system malfunction	7	OFF
EE	Water level alarm malfunction	8	OFF
E8	Dual indoor unit (twin model only) communication malfunction	9	OFF
E9	Other twin model malfunction	10	OFF
F0	Overload protection	1	ON
F1	Outdoor temperature sensor error	2	ON
F2	Outdoor condensor pipe sensor error	3	ON
F3	Discharge air temperature sensor error	4	ON
F4	Outdoor EEPROM error	5	ON

F5	Outdoor fan speed (DC fan motor only) malfunction	6	ON
F6	T2b sensor error	7	ON
F7	Auto-lifting panel communication error	8	ON
F8	Auto-lifting panel malfunction	9	ON
F9	Auto-lifting panel is open	10	ON
P0	Inverter module IPM protection	1	Flash
P1	High/Low voltage protection	2	Flash
P2	Compressor top overheating protection	3	Flash
P3	Outdoor low temperature protection	4	Flash
P4	Compressor drive error	5	Flash
P5	Mode conflict	6	Flash
P6	Compressor low-pressure protection	7	Flash
P7	Outdoor IGBT sensor error	8	Flash