## **Technical Information**

Model		Enviro 16	Enviro 26	Enviro⁺32
Bathrooms^		1	1-2.5	2.5+
Installation		External	External	External
Heating Capacity L/Min	Raised at 20°C	20	26	37
	Raised at 25°C	16	26	32
	Raised at 40°C	10	16	20
Height (inc. brackets)		565	565	721
Width		351	351	470
Depth (inc. brackets)		191	191	276
Weight		16kg	18kg	29kg
Main Gas Rate		110MJ/h	175MJ/h	209MJ/h
Cold Water Connection (mm)		15 (1/2")	20 (3/4")	20 (3/4")
Hot Water Connection (mm)		15 (1/2")	20 (3/4")	20 (3/4")
Gas Connection (mm)		20 (3/4")	20 (3/4")	20 (3/4")
Minimum Operating Flow (L/Min)		1.5	1.5	1.5
Factory Pre-set Temperature (°C)		50#/60	50#/60	60
Combustion NOx Levels (ppm)		40	40	35
Colour		Silver	Silver	Silver
Ignition		Direct electronic ignition with automatic flame sensing		
Gas Type		NG/LPG		
Electrical Supply		AC 240V 50 Hz		
Water Controllers		Up to 4 Water Controllers can be installed		
Heat Exchanger Warranty		Up to 25 years*		
Parts and Labour Warranty		3 Years (5 Years if two or more Water Controllers are installed in domestic applications)		

<sup>^</sup> Sizing assumes AAA or \*3 star outlets. For non WELS rated or WELS rated fixtures with higher flow outlets (AA, A, 2 star or 1 star rated) a larger size appliance or additional appliance may be required to deliver adequate performance. This is a guide only, special site and location factors may affect this. Half a bathroom refers to a guest shower or powder room that is not used all the time. For more information, consult with your

Capacities tested in accordance with AS/NZS 5263.1.2. With our policy of continuous improvement, we reserve the right to change, or discontinue at any time, specifications or designs without notice.

Note: All images contained within this brochure are for illustrative purposes only, the colours and finishes of the products featured are as close to the respective product range as photographic lighting and printing processes allow.

<sup>\*</sup>Adjustable up to 53°C. For 60°C plus installations a tempering valve in accordance with AS3500.4 is required.

\*For Infinity Enviro and Enviro\* models the standard warranty is 12 years for the primary heat exchangers and 3 years parts and labour. The new condensing models have been added to Rinnai's extended warranty program, extending the warranty on the primary heat exchangers by a further 13 years taking it to a total of 25 years.