

Efinity Continuous Flow 19kW

ECF19I50 and ECF19I60

ERROR CODES

Fault Code	Description
E1	Sensor Failure
E2	Outlet temperature exceeds 75 degrees celcius
E3	Outlet temperature exceeds 85 degrees celcius
EC	Communication Error Between PCB Boards
EC	Communication Error Between PCB Boards