

Security Bracket

Installation Instructions

GENERAL INFORMATION

This Rinnai security bracket is suitable for installation with all Rinnai Hot Water Heater systems.

INSTALLATION METHOD

1. Determine the most suitable position for the Rinnai hot water heater;
2. Affix the appliance via the top-supporting bracket.
3. Fit the back security bracket behind the lower bracket on the Rinnai Hot Water Heater, allowing the centre pin to protrude through the centre keyhole of the lower bracket (Figure 1).





Figure 1

4. With the brackets in position, mark the position for the two fixing points.
5. Drill two 8mm holes, insert and fix Dyna bolts or equivalent (not supplied) to secure both lower brackets.
6. Connect the gas and water connections.
7. Commission the Infinity hot water heater.
8. Fit the front security bracket so that it covers both the appliance bracket and securing bolts, ensure that the outer sides (A) of the front security bracket are fitted inside the sides of the rear security bracket (B).
9. Attach a padlock and make sure that the keys are left with the owner of the appliance (Figure 2).



Padlock to be provided by installer/owner, padlock shank diameter not to exceed 6mm, inner shackle length no shorter than 50mm, for example Lockwood 120/30/150 or equivalent. Remind the owner to tag and keep the keys in a safe location as they may be required for future access.

For further information, please contact the Rinnai Customer Care Centre on 1300 555 545.

Rinnai Australia Pty Ltd

ABN 74 005 138 769 AU45204
82-88 Mills Road, Braeside, Victoria, 3195
P.O. Box 460, Braeside, Victoria 3195
Tel: (03) 9271 6625

Customer Support

Tel: 1300 555 545*

Hot Water Service Line

Tel: 1800 000 340*

**Cost of a local call may be higher from a mobile phone.
(National calls from public phones in Australia are free.)*

For further information visit www.rinnai.com.au or email enquiry@rinnai.com.au

Rinnai has a Service and Spare Parts network with personnel who are fully trained and equipped to give the best service on your Rinnai appliance.

If your appliance requires service, please call Customer Support. Rinnai recommends that this appliance be serviced every 2 years.

With our policy of continuous improvement, we reserve the right to change, or discontinue at any time, specifications or designs without notice.