


Honeywell Home





Quick reference



HOME. Touch to display Home screen.

FAN. Select fan mode.

SYSTEM. Select system mode (heat/cool).

MENU. Touch to display options. Start here to set a program schedule.

*Thermostat location. Quickly identify which thermostat is in control of a specific area.

Current schedule. Touch an arrow to change temperature setting and set a temporary hold.

*Override. Touch to temporarily override the program schedule.

Indoor conditions. Shows indoor temperature and humidity.

Current date and time.

Current status. Shows system mode (heat/cool).

Outdoor conditions. Outdoor temperature and humidity appear after registration.

Connecting to your Wi-Fi network

- 1. If thermostat is asking if you want to connect to a Wi-Fi network, touch Yes. If thermostat is not asking if you want to connect to a Wi-Fi network, Touch MENU > Wi-Fi Setup.
- Touch the name of the network you want to use. The thermostat displays a password page.
- Using the keyboard, touch the characters that spell out your home network password.

NOTE: If your home network is not shown on the list, touch Rescan.

- Touch **Done**. The thermostat displays "Connecting to your network. Please wait..." then shows a "Connection Successful" screen.
- Touch Next to display the registration information screen.
- Note your Thermostat MAC and Thermostat CRC. You need these numbers to complete online registration.

Disconnecting your Wi-Fi network

If you need to disconnect the thermostat from your Wi-Fi network (for example, you're replacing your router), follow these steps:

- Touch MENU.
- Select Wi-Fi Setup.
- Touch Disconnect from Network. The thermostat will display a question to confirm your selection.
- Touch Yes to confirm that you want to disconnect from the network.
- Touch **OK** to display the menu.

Reconnecting your Wi-Fi network

- 1. Touch MENU.
- Select Wi-Fi Setup.
- Touch the name of the network you want to use. The thermostat may display a password page.
- To enter a password, touch characters to spell out your home network password, then touch Done.
- The thermostat displays "Connecting to your network. Please wait..." then a "Connection Successful" screen.
- 6. Touch Next.
 - If your thermostat is registered, you will see your signal strength and other status information. Touch Done.
 - If the screen displays "Register Online for Remote Access." follow instructions on page 3 in 69-2814EFS.

Setting the time/date

- Touch the current time. The screen displays Set Time/Set Date.
- Touch Set Time or Set Date.
- Touch ▲ or ▼ until the proper time/date is displayed.
- Touch Done to save or Cancel to ignore changes.

Setting system mode

- Touch **SYSTEM** to display system settings.
- Touch desired option: Heat, Cool, Off, Automatic, Emergency Heat (heat pumps with aux. heat).
- Touch Done to save and exit.

NOTE: The Automatic and Emergency Heat system settings may not appear, depending on how your thermostat was installed.

Adjusting program schedules

- 1. Touch MENU.
- 2. Select Create/Edit Schedule.
 - Touch View/Edit to view the full schedule and make a quick adjustment.
 - Touch **Guide Me** to create a schedule by answering simple questions.

Product Manuals

Search online for Resideo 69-2814EFS for the User Guide.

Videos

Search online for Smart Thermostat 9000.

Need Help?

For assistance please visit http://honeywellhome.com, or call toll-free: 1-800-633-3991



^{*}Settings and display will vary depending on whether thermostat is set for residential or business. Search online for **Resideo 69-2814EFS** for the User Guide to see all options.