MODELS System HSNRP26 HSNRP35 HSNRP50 HSNRP60 HSNRP70 HSNRP80	Indoor HINRP26M HINRP35M HINRP50M HINRP60M HINRP70M HINRP80	Outdoor HONRP26 HONRP35 HONRP50 HONRP60 HONRP70 HONRP80	REFRIGERANT R32
Ref Only	HINRP20M	Matching Multi System Only	

	26.5
Rinnal	

P Series Split Type Wall Mounted Air Conditioner Wireless Smart Kit Operation Manual

Rinnai

IMPORTANT NOTE:

Read the manual carefully before installing or connecting your Smart kit (Wireless module). Make sure to save this manual for future reference.

DECLARATION OF CONFORMITY

Hereby, we declare that this Smart kit is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. A copy of the full DoC is attached. (European Union products only)

CONTENTS

0	SPECIFICATION	1
2	PRECAUTIONS	1
	DOWNLOAD AND INSTALL APP	
	INSTALL THE SMART KIT	
	USER REGISTRATION	
	NETWORK CONFIGURATION	
ð	HOW TO USE APP	16
	SPECIAL FUNCTIONS	

1 SPECIFICATION

Model: OSK102,EU-OSK103,US-OSK103 Standard: IEEE 802. 11b/g/n Antenna Type: Printed PCB Antenna Frequency : WLAN 2400~2483.5 MHz Operation Temperature:0°C~45°C/32°F~113°F Operation Humidity: 10%~85% Power Input: DC 5V/300mA Maximum Transmitted Power: 19.8dBm Max

2 PRECAUTIONS

- Applicable system: iOS, Android.
 (Suggest: iOS 8.0 or later, Android 4.0 or later)
- Please keep you APP up to date with the latest version.
- Due to special situation may be occurred, we explicitly claims below: Not all of the Android and iOS system are compatible with APP. We will not be responsible for any issue as a result of the incompatibility.

Wireless safety strategy Smart kit only support WPA-PSK/WPA2-PSK encryption and none encryption. WPA-PSK/WPA2-PSK encryption is recommended.

- Cautions
- Due to different network situation, control process may return time-out sometimes. If this situation occurs, the display between board and App may not be the same, please do not feel confused.
- Smart Phone camera needs to be 5 million pixels or above to make sure scan QR code well.

- Due to different network situation, sometimes, request time-out could happen, thus, it is necessary to do network configuration again.
- The APP system is subject to update without prior notice for product function improvement. The actual network configuration process may be slightly different from the manual, the actual process shall prevail.
- Please Check The Service Website For More information.

3 DOWNLOAD AND INSTALL APP

<u>CAUTION</u>: The following QR Code is only available for downloading APP. It is totally different with the QR code packed with SMART KIT.





Android

iOS


- Android Phone users: scan Android QR code or go to google play, search 'NetHome Plus" app and download it.
- iOS users: scan iOS QR code or go to APP Store, search 'NetHome Plus" app and download it.



4 INSTALL THE SMART KIT(wireless module)

NOTE:

- The P Series wall mounted split system indoor unit has been pre-fitted with the Wireless Smart Kit. Please proceed to Step 5 on page 4 of this manual.
- Remove the protective cap of the smart kit (wireless module)
- ② Open the front panel and insert the smart kit (wireless module) into the reserved interface.
- ③ Attach the QR code packed with Smart kit (wireless module) to the side panel of the machine, ensure it is convenience to be scanned by the mobile phone. Alternatively, user can take picture of the QR Code and save it into their own phones.



WARNING: This interface is only compatible with SMART KIT (wireless module) provided by the manufacturer.

5 USER REGISTRATION

- Please ensure your mobile device is connected to Wireless router. Also, the Wireless router has already connected to Internet before doing user registration and network configuration.
- It is better to log in your email box and active your registration account by clicking link in case you forget the password. You can log in with the third party accounts.

•••• •• 🗢		50% 💷	•••• 🗢 🗢	8:08 AM	50% 💷
			K Back		
	(1)		Enter your e	mail address	
			password		0
				Registration	
1234567@mail.com	n	0		negistration	
Password		•	I have re	and agree to the Terms	and Privacy.
1 00011010		~			
	1				
	Login				
Log in v					
	fly				
te	cebook twitter				
Forgot password?		Sign up			

① Click "Sign up "

② Enter your email address and password, and then click "Registration"

6 NETWORK CONFIGURATION

Cautions

- It is necessary to forget any other around network and make sure the Android or iOS device just connect to the Wireless network you want to configure.
- Make sure the Android or iOS device Wireless function works well and can be connected back to your original Wireless network automatically.

Kindly reminder:


User must finish all the steps in 8 minutes after powering on air conditioner, otherwise you need to power on it again.

Using Android device to do network configuration

- ① Make sure your mobile device has already been connect to the Wireless network which you want to use. Also, you need to forget other irrelevant Wireless network in case it influences your configuration process.
- ② Disconnect the power supply of air conditioner.
- ③ Connect the power supply of AC, and continuously press the "LED DISPLAY" or "DO NOT DISTURB" button seven times in 10 seconds.
- When the unit displays "AP", it means that the air conditioner wireless has already entered into "AP" Mode.
- Some type of air conditioner do not need the ② step to be in AP.

•••• *	8:08 АМ Ноте	50% 💷	••••00 3		8:08 AM	50% 💶 🔿
	ноте	\$	< Ba	ck	Add method	
			Selec		iance you are setting up	
				Split-ty	•	>
	1234568 User name		0	Portabl	e AC	>
			•	Window	w AC	>
			0	Humidi	ifier	>
	+ Add Device		0	Dehum	idifier	>
	+ Add Shared Device					
(5) Pres	s " + Add Devic	е"	(6) S	Select	t the applian	ce vou

Select the appliance yo are setting up



 \bigcirc Follow the above steps to enter "AP" mode.








8 Choose the network configuration method.

(9) Choose the "Scan the QR code " method.







(9) Or choose the "Manual Setup" method.


10 Please enter password






- Using iOS device to do network configuration
- ① Make sure your mobile device has already been connected to the Wireless network which you want to use. Also, you need to forget other irrelevant Wireless network in case it influences your configuration process.
- 2 Disconnect the power supply of AC(some units).
- ③ Connect the power supply of AC, and continuously press the "LED DISPLAY" button or "DO NOT DISTURB" button seven times in 10 seconds.
- ④ When the AC displays "AP", it means that the AC Wireless has already entered into "AP" Mode.





 \bigcirc Follow the above steps to enter "AP" mode.






⑧ Connect to the Wireless network.

9 Please enter password





on the list.




NOTE:

 When finishing network configuration, APP will display success cue words on the screen.

Due to different internet environment, it is possible that the device status still display "offline". If this situation occurs, it is necessary to pull and refresh the device list on the APP and make sure the device status become "online". Alternatively, user can turn off the AC power and turn on it again, the device status will become "online" after few minutes.

7 HOW TO USE APP

Please ensure both your mobile device and air conditioner are connected to the Internet before using app to control the air conditioner via internet, please follow the next steps:



16

① Click "Sign up "

2 Choose the air conditioner.



(3) Thus, user can control air conditioners on/off status, operation mode, temperature, fan speed and so on.

NOTE:

Not all the function of the APP is available on air conditioner. For example: ECO, Turbo, Swing function, please check the user manual to find more information.

8 SPECIAL FUNCTIONS

Including: Timer on, Timer off, 8° C Heat, Sleep, Check.

NOTE: If the air conditioner do not support the above function, the function will be hided from the function list.

Timer on/Timer off

Weekly, user can make an appointment to turn on or off AC on specific time. User also can choose circulation to keep the AC under schedule control every week.

•••• ፡፡ 🗇	8:08 AM	50% 💷	••••0 🗢		50% 💷
K Back		۵	K Back		•
Timer On	18:00 Mon. Tues.		Timer On	18:00 Mon. Tues.	
Timer Off	02:00 Mon. Tues.	\bigcirc	Timer Off	02:00 Mon. Tues	\bigcirc
8° Heating		\bigcirc	8° Heating		\bigcirc
Sleep	-M	\bigcirc	Sleep	-Mr-	\bigcirc
Check		>	Check		>
About		>	About		>
Share device		>	Share devic	e	>
		18			

•••• ?		B AM	50%	•••⊷ ≉ ≮ Back	8:08 AM	50% 💷 🔿
< Back	LIME	ər On	ОК	С васк	Repeat	
	24 H	12 H				
				Monday		0
				Tuesday		0
				Wednesday		
	10	05		wednesday		
	11	06		Thursday		
				Friday		
				Saturday		
Repeat		Mo	n.Thur, >	Sunday		

■ 8°C Heat

User can let the AC run under 8°C Heat by one-click. When people go outside, this function can protect your furniture from frost damage.

•••• 🗢 🗢	8:08 AM	50% 💶)
		۰
Timer On	18:00 Mon. Tues.	
Timer Off	02:00 Mon. Tues.	\bigcirc
8° Heating		\bigcirc
Sleep	-M-	\bigcirc
Check		>
About		>
Share device		>



Sleep


User can customise their own comfortable sleep by setting target temperature.

•••••	8:08 AM	50%	•••• 🗢 🗢	8:08 AM	50% 💷
K Back	Fuction	۵	< Back		
Timer On	18:00 Mon. Tues.		°C 29 28		
Timer Off	02:00 Mon. Tues.	\bigcirc	28 27 26 25	\sim	<u></u>
8° Heating		0	24 23 22 21 20 19 18	× ~	~
Sleep	-^/-	\bigcirc	0h 2h	4h	6h 8h
Check		>	edit		0
About		>	young		
Share device	9	>	Elder		
			Children		



Check

User can simply check the AC running status with this function. When finishing this procedure, it can display the normal items, abnormal items, and detail information.



Share Device

The air conditioner can be controlled by multi-users at the same time by Share Device function.

****:> 🕈	8:08 AM	50% 💷 🔿	•••• 00 🕾	8:08 AM	50% 💷
<			<		
Timer On		>			
Timer Off		>			
Sleep curve		>			
Energy Monitor		>		Sinte	
Bill Control		>			
Check		>			
Units	(F	τ	Air APF	ease ask your family to use on their own mobile phones code and share this device t	to scan
Share device		>	this OH	code and share this device t	io them.
About device		>			
	Delete				

① Click "Share device"

2 QR code display.



•••• 🗢 🗇	8:08 AM Appliance	50% -	•••• >> 🗢	8:08 AM Appliance	50% 💶)
	+ Add Device			+ Add Device	
0	AC2330	Online >	C AC	2330	Online >
	+ Add Shared Device			+ Add Shared Dev	ce
			C AC:	2340	Online >
	Ø	0			S.
Appli		Q. Me	Appliance	Discover	Mo

21

③ The other users must log ④ Now the others can in "Nethome Plus" app first, then click "Add Share Device" on their own mobile, then ask them to scan the QR code.

add the shared device.

CAUTIONS:

For models of US-OSK103, EU-OSK103: FCC ID:2AS2HMZNA19 IC:24951-MZNA19

For model of OSK102: FCC ID:2AS2HMZNA18 IC: 24951-MZNA18

This device complies with Part 15 of the FCC Rules and Industry Can ada's lice nce-exempt RSS standards. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Only operate the device in accordance with the instructions supplied.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, human proximity to the antenna shall not be less than 20cm (8 inches) during normal operation. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device. pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception. which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: --Reorient or relocate the receiving antenna.

- --Increase the separation between the equipment and receiver.
- --Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- --Consult the dealer or an experienced radio/TV technician for help.

Company will not be liable for any issues and problems caused by Internet, Wireless Router and Smart Devices. Please contact the original provider to get further help.



Rinnai Australia Pty Ltd

ABN 74 005 138 769 | AU45204

100 Atlantic Drive, Keysborough, Victoria 3173 PO. Box 460, Braeside, Victoria 3195 Tel: (03) 9271 6625 Fax: (03) 9271 6622

National Help Line

Tel: 1300 555 545* Fax: 1300 555 655 Monday to Friday, 8.00 am to 5.00 pm EST.

*Cost of a local call may be higher from a mobile phone. (National calls from public phones in Australia are free.)

For further information visit www.rinnai.com.au or email enquiry@rinnai.com.au

Rinnai has a Service and Spare Parts network with personnel who are fully trained and equipped to give the best service on your Rinnai appliance. If your appliance requires service, please call our National HelpLine.

With our policy of continuous improvement, we reserve the right to change, or discontinue at any time, specifications or designs without notice.